


Configure Metrologic Scanner for GoAntiquing!


Please scan the codes in the numbered order.

1. Enter Program Mode




999999

6. Disable Line Feed




116602

2. Clear USB Setting




816400

7. Enable Comm Timeout




118412

3. Recall Defaults




999998

8. Beep After Transmit




118403

4. Minimum Symbol Length




801800

9. Exit Program Mode



999999

5. Programmable Prefix 1



80351240