


***** Scan this "reset" code first. *****



Response: beep,boop,beep

Configure Metrologic Scanners 1690, 3780, 9590 For use with GoAntiquing! Point-of-Sale

1. Enter Program Mode




999999

Response: beep,beep,beep

Scan codes in numbered order, but start with the special "reset" code at top of page!


6. Disable Line Feed



116602

Response: beep


2. Clear USB Setting



816400

Response: beep


7. Enable Comm Timeout



118412

Response: beep


3. Recall Defaults



999998

Response: beep


8. Beep After Transmit



118403

Response: beep


4. Minimum Symbol Length



801800

Response: beep


9. Exit Program Mode



999999

Response: beep,beep,beep

5. Programmable Prefix 1



80351240

Response: beep